

## REPLACING THE MAT:

Step 1: Start with the unit folded. (Please reference folding instructions for your safety)



Remove the other half of the springs from the frame (optional, but recommended). Continue around the frame of the Rebounder until all mat springs have been removed, and set mat springs aside.



Step 2: Remove the yellow spring guards (if attached). Set Aside.



Step 4: Remove all the "W" hooks from the mat, and set aside. Discard old mat.



Step 3: Pull the springs off of the hooks that attach the springs to the mat ("W" hooks).



Step 5: Attach the “W” hooks to the new mat.



Re-attach the springs to the eye bolts on the frame and on the “W” hooks that attach the springs to the mat.



Add the yellow spring guards right after each spring is added. You may need to use the spring tool to pull the springs to the matt and attach. Continue around the frame and repeat until all springs are attached to the frame and mat.



Step 6: With the Rebounder open and legs pointing up (**please reference opening instructions for your safety**), start with the spring closest to the hinge.

