

REPLACING THE LEG SPRING: With Cotter Pin Tools

Step 1: Turn Rebounder upside down with legs pointing up.



Step 2: Remove the rubber tip from the leg that needs replacing. Set aside.



Step 3: Inside of the leg, you will see a hook where the spring attaches to the leg. Using the Spring Tool, hook the tool to the spring and pull up.



Detach the spring from the leg. Remove the leg and set aside.



Step 4: Using the Cotter Pin Tool or other similar tools (a small screwdriver, hammer, and pliers), remove the cotter pin from the leg base. This will allow the spring to release. Discard old spring.



Step 5: Place new spring into the leg base and reattach the cotter pin by lightly tapping with a hammer or similar tool until the cotter pin is back in place.



Step 7: Reattach the rubber tip.



Step 6: Reattach the leg by sliding it over the new spring. Using the Spring Tool, hook the spring and lift over the hook on the leg.

